

On His Majesty's Service

WAR ECONOMY 1944
OPEN by slitting top edge
RE-USE with Economy Label



A.C. Clague
Post-office
Lawsoning
Wilgetts Prints.

If undelivered, return to:-
The National Savings Committee,
Sanctuary Buildings,
E.C.4 Westminster, S.W.1.

Abbreviated Notes for Home Guard Instructors (Continued)

STOP PAGES VICKERS
MACHINE G.N

Position.	Preparation.	I.A.	Prevention.	Probable Cause.
1st. Half Load, Pull Crank Handle slowly until Horns of Extractors engage on steps of solid Cans, Belt to Left. All cases where not weak Charge, repeat. To set up for weak or Broken Gib spring. Old out Lock, slide round on lower half of protection of Gib. Belt to Left.		Pull Crank Handle on Roller belt to left, let go C.H. If failure recurs lighten Fuzee spring three clicks. If C.H. remains in 1st. Pos. C.H. on roller out lock "New Lock" Remove round Change Lock.	Attend to Points Before Firing.	1. Weak Charge 2a Heavy Fuzee Spring (b) Want of oil in working Parts (c) Grit in Working Parts. (d) Excessive Packing (e) Worn Barrel (f) Tight Pockets (g) Friction due to frozen oil or water. 3. Weak or Broken Gib Spring.
2nd. Insert Bulged Round in first pocket in Belt & Load. Change. Bulged Dummy in Belt. Half Load, open rear Cover out Lock place Separated Case over round, replace Lock, Close rear cover, C.H. slowly on Check lever. Telescoped round, Half Load out Lock, remove round place round with S.C. on Extractors. Close R.C. Belt to Left.		Force C.H. to Rear Call out "Clearing Plug" Open Rear Cover examine round on extractors, if damaged "Don't want it" Remove round, Reload. If good round remove use clearing plug. "Don't want it!"	If separations occur, change lock. If still occur. Call No. 1 & No. 2. Washers over connecting rod. Armorer to adjust.	Damaged Cartridges Separated Case. Separated Case on round.
3rd. Half Load Crank Handle raise rear Cover pull belt over Till round is half way on face of feed block, crank handle slowly forward till Stops in 3rd. position lower rear cover. Proceed to load but ease Crank handle forward to 3rd. position. In friction, repeat. Pull 4th round in belt		Slightly raise C.H. Belt to left. let go C.H. Strike down. If occurs. Repeat, Unload of 1 working parts, reload. If above fails, Feed slide. "Fixed" call "Feed block"	Attend to Points Before Firing. Friction in the Lock. Badly filled belts are the chief Cause.	Slightly cross fed round.

Bent or Damaged brass strips.
badly filled belt
Worn or loose